


Updating an OmniTouch 7 to a BitWise Touchscreen

To update an OmniTouch 7 to a BitWise Touchscreen:


- 1) Using Project Editor 1.9.96 or later, open a project and select **Tools** and then **Firmware Updater** from the menu.



- 2) All OmniTouch 7 touchscreens on the network will be displayed in the **Available Units** list.



- 3) Highlight the unit that you want to update and then press the **Update Firmware** button.

**Notes:**

- a) The **Firmware File** will be: **BitWiseOT7_Version_1.9.17.apk.ot7f** or higher
- b) The current firmware (**Current FW**) in the OmniTouch 7 must be Version 1.7 or higher

If the current firmware in the OmniTouch 7 is not Version 1.7 or higher, you will be prompted to updated in now.

